

Concrete Collaborative Concrete Floor Tiles



SCOPE - To mechanically buff clean and protective seal the concrete collaborative concrete tiles.

NOTES TO SPECIFIER

- Refer to PROSOCO, Inc. CSI compliant system specifications for guide language which can be found at <http://www.prosoco.com/FinishedConcrete>.

INSTALLATION MATERIALS

Floor Tiles: LAGUNA, SOLANA, VENICE, and TRAILS series tiles produced by Concrete Collaborative: www.concrete-collaborative.com.

Tile Protective Sealer: Consolideck® PolishGuard for interior application, Consolideck® GuardEXT for exterior applications

PREPARATIONS

Prior to commencing installation, the Contractor is to examine substrates and advise the General Contractor and Architect of all existing conditions and surface contamination which will require correction, before the work commences. Before starting, remove protection from tiles and sweep the floor.

Wet-scrub the floor with a floor machine using Consolideck DailyKlean and a white Twister™ Pad from HTC. Work in sections making six to eight passes or until a slurry develops. Make sure to overlap each pass. Be diligent in removing dirty water and slurry before drying.

APPLICATION OF PROTECTIVE TREATMENT FOR INTERIOR INSTALLATION OF TILE

1. Apply per manufacturer's published recommendations to a clean, dry Concrete Collaborative Tile at the completion of surface cleaning operation.
2. Lightly wet a clean microfiber pad with Consolideck PolishGuard and wring out excess, leaving the pad damp.
3. Spray-apply protective treatment using a clean, pump-up sprayer fitted with a 0.5 gpm conical or fan spray tip at an estimated coverage rate of 1200 to 1500 square feet per gallon.
4. Protective treatment should be applied to produce a natural finish with little or no gloss.
5. Spread with the damp microfiber pad. Maintain a thin, even coating and wet edge. Stop spreading once drying begins. Do not overlap. (for vertical application you may back-roll any drips or run-down of excess product or seal the tile prior to installation)
6. Allow the surface to dry tack-free, typically 30-60 minutes.
7. Repeat steps 1 through 4. Two coats are recommended for maximum protection.

APPLICATION OF PROTECTIVE TREATMENT FOR EXTERIOR INSTALLATION OF TILE

1. Apply per manufacturer's published recommendations to a clean, dry Concrete Collaborative Tile at the completion of surface cleaning operation.
2. Lightly wet a clean microfiber pad with Consolideck Guard EXT and wring out excess, leaving the pad damp.
3. Spray-apply protective treatment using a clean, pump-up sprayer fitted with a 0.5 gpm conical or fan spray tip at an estimated coverage rate of 1200 to 1500 square feet per gallon.
4. Protective treatment should be applied to produce a natural finish with little or no gloss.
5. Spread with the damp microfiber pad. Maintain a thin, even coating and wet edge. Stop spreading once drying begins. Do not overlap. (for vertical application you may back-roll any drips or run-down of excess product or seal the tile prior to installation)
6. Allow the surface to dry tack-free, typically 30-60 minutes.
7. Repeat steps 1 through 4. Two coats are recommended for maximum protection.

MAINTENANCE

1. Mop or auto-scrub regularly with warm water and Consolideck DailyKlean
2. Concrete is particularly sensitive to acids like lemon juice or vinegar, so care should be taken to wipe up spills immediately and spot clean the floor using Consolideck DailyKlean
3. The application of protective treatments process above may be repeated as necessary over time for added protection against spills using client discretion.

CUSTOMER CARE

Factory personnel are available for product, environment and job-safety assistance with no obligation. Call 800-255-4255 and ask for Customer Care - technical support.

Factory-trained representatives are established in principal cities throughout the continental United States. Call Customer Care at 800-255-4255, or visit our web site at www.prosoco.com, for the name of the Consolideck® representative in your area.